

iVIEW Suite for Microsoft OCS 2007 and 2007 R2 Version 7.0



NOTICE

© 2000-2009 RADVISION Ltd. All intellectual property rights in this publication are owned by RADVISION Ltd and are protected by United States copyright laws, other applicable copyright laws and international treaty provisions. RADVISION Ltd retains all rights not expressly granted.

This publication is RADVISION confidential. No part of this publication may be reproduced in any form whatsoever or used to make any derivative work without prior written approval by RADVISION Ltd.

No representation of warranties for fitness for any purpose other than what is specifically mentioned in this guide is made either by RADVISION Ltd or its agents.

RADVISION Ltd reserves the right to revise this publication and make changes without obligation to notify any person of such revisions or changes. RADVISION Ltd may make improvements or changes in the product(s) and/or the program(s) described in this documentation at any time.

If there is any software on removable media described in this publication, it is furnished under a license agreement included with the product as a separate document. If you are unable to locate a copy, please contact RADVISION Ltd and a copy will be provided to you.

Unless otherwise indicated, RADVISION registered trademarks are registered in the United States and other territories. All registered trademarks recognized.

GoAhead WebServer is used by permission from GoAhead Software, Inc. GoAhead WebServer is used by permission from GoAhead Software, Inc. Copyright © 2006 GoAhead Software, Inc. All Rights Reserved.

For further information contact RADVISION or your local distributor or reseller.

iVIEW Suite version 7.0, June 2009

Publication 2

<http://www.radvision.com>

ABOUT THIS MANUAL

The [iVIEW Suite for Microsoft Office Communicator Server 2007 User Guide](#) provides information on the basic configuration required to enable users to work with the iVIEW Suite window in Microsoft Office Communicator Server 2007.

RELATED DOCUMENTATION

Documentation is available on the RADVISION Utilities and Documentation CD-ROM supplied with the product and includes manuals and online helps. The manuals are in PDF format.

Note You require Adobe Acrobat Reader version 6.0 or later to open the PDF files. You can download Acrobat Reader free of charge from www.adobe.com.

CONVENTIONS USED IN THIS MANUAL

Microsoft Office Communicator Server 2007 is sometimes referred to as “OCS” throughout this manual.

FEEDBACK

The team at RADVISION constantly endeavors to provide accurate and informative documentation. If you have comments or suggestions regarding improvements to future publications, we would value your feedback.

Please send your comments to doc_comments@radvision.com.

We thank you for your contribution.

USING THE MICROSOFT OFFICE COMMUNICATOR SERVER (OCS) 2007 SCOPIA WINDOW

- [Installing the OCS 2007 Client](#) on page 1
- [Configuring the OCS 2007 Client](#) on page 1

INSTALLING THE OCS 2007 CLIENT

Contact your system administrator for installation information.

CONFIGURING THE OCS 2007 CLIENT



Procedure

- 1 Open the OCS 2007 client.
The SCOPIA window displays at the bottom of the OCS client screen.

Configuring the OCS 2007 Client



- 2 Click the **Virtual Room Settings** link to access your virtual room profile.

The screenshot shows the 'Virtual Room Settings' dialog box. It has a green header bar with the title 'Virtual Room Settings' and a 'Log Out' link on the right. The main area contains several fields: 'Virtual Room Name' (text box with 'Ian's Virtual Room'), 'Meeting Type' (dropdown menu with '86 - desktop Video'), 'Virtual Room Number' (text box with '60006'), 'Meeting PIN' (text box with '1111'), and 'Moderator PIN' (text box with '1111'). There are green question mark icons next to the PIN fields. A checkbox labeled 'Place participants in a 'waiting room' until the moderator joins the meeting' is located below the PIN fields. At the bottom of the dialog are 'OK' and 'Cancel' buttons.

- 3 (Optional) Modify your virtual room name and PINs.
- 4 To access a virtual room or to join an ad hoc meeting, enter the virtual room number or the meeting ID in the Meeting ID field and click **Join**.
- 5 If the meeting is PIN-protected, enter the PIN in the Meeting PIN field and click **OK**.


Note OCS client video sessions do not support functionalities such as chat, invite or file sending.

- 6 On the client machine desktop, answer the incoming call from the MCU.




The call connects and the SCOPIA window indicates that the meeting is in progress.

Note When an OCS client connects to the MCU for the first time, you might need to wait a few seconds before the video displays correctly.




- 7 Click **Moderate** to open the Conference Control screen for managing live meetings.
- 8 Enter the Moderator PIN if the meeting is protected.

Configuring the OCS 2007 Client




- 9 Click **OK** to display the iVIEW Suite Conference Control screen.
- 10 To disconnect from the SCOPIA meeting, perform one of the following:
 - Terminate the call from the video window, or



- Click **Disconnect** in the SCOPIA window.



Once the call is disconnected, the entry screen is displayed again in the SCOPIA window.





www.radvision.com

About RADVISION

RADVISION (NASDAQ: RVSN) is the industry's leading provider of market-proven products and technologies for unified visual communications over IP and 3G networks. With its complete set of standards based video networking infrastructure and developer toolkits for voice, video, data and wireless communications, RADVISION is driving the unified communications evolution by combining the power of video, voice, data and wireless – for high definition video conferencing systems, innovative converged mobile services, and highly scalable video-enabled desktop platforms on IP, 3G and emerging next generation networks. For more information about RADVISION, visit www.radvision.com

USA/Americas
T +1 201 689 6300
F +1 201 689 6301
infoUSA@radvision.com

EMEA
T +44 20 3178 8685
F +44 20 3178 5717
infoUK@radvision.com

APAC
T +852 3472 4388
F +852 2801 4071
infoAPAC@radvision.com